

# CFD helping to mitigate COVID transmission

**Project Title:** Opensource software simulations towards understanding, monitoring and controlling COVID-19 transmission by managing air, people distancing and adapting urban environments

**Project number:** 85435


**Competition:** UKRI Ideas to address COVID-19 – Innovate UK de minimis Aug'20

**Funding body:** Innovate UK

**OpenCFD Limited, UK**

F Mendonça, P Ghildiyal, A Heather, K Bercin,

with contributions from ESI-Group's P Sonakar, P Jaganathan, R Magg



**Advanced Modeling and Simulation (AMS) Seminars Series**

**NASA Ames Research Center, July 15<sup>th</sup>, 2021**

# CFD (OpenFOAM®) in the COVID-19 battle

## Global acceptance of aerosol airborne transmission mechanism

- World Health Organisation (09-July-2020)

*“Transmission of SARS-CoV-2 can occur through direct, indirect, or close contact with infected people through infected secretions such as saliva and respiratory secretions or their respiratory droplets, which are expelled when an infected person coughs, sneezes, talks or sings. Respiratory droplets are  $>5\text{-}10\text{ }\mu\text{m}$  in diameter whereas droplets  $\leq 5\text{ }\mu\text{m}$  in diameter are referred to as droplet nuclei or aerosols.”*

- Professional Bodies

- ASHRAE (05-April-21)


*“Airborne transmission of SARS-CoV-2 is significant and should be controlled. Changes to building operations, including the operation of heating, ventilating, and air-conditioning systems, can reduce airborne exposures.”*

- CIBSE with SAGE, UK (23-Oct-2020)

*“Ventilation is an important factor in mitigating against the risk of far-field ( $>2\text{m}$ ) aerosol transmission”*

- IMechE (current COVID-19 Manual)

*“Airborne transmissions can transmit small particulates through the air over time and distance. Airborne transmissions are usually distinct from transmission by respiratory droplets. Respiratory droplets are droplet particles greater than  $5\text{-}10\text{ }\mu\text{m}$  in diameter whereas droplets less than  $5\text{ }\mu\text{m}$  are referred to as droplet nuclei.”*




# CFD (OpenFOAM®) in the COVID-19 battle

## AGENDA

- **Statement of need**
  - How effective is the internal room ventilation regarding fresh/clean air circulation?
  - What happens to viral load from contamination sources?
- **Validation of underlying flow physics**
- **Useful measures for good ventilation**
- **Some case studies**
  - Operating theatre
  - Community centre
  - Restroom
  - Canteen / restaurant
  - Assembly plant
  - Office (executive, open-plan, connected)
  - UK C-19 Mobile Testing Unit
  - Dental and Endoscopy treatment rooms with AGPs and fallow time

IsoSurface of Age of Air at 50 sec



# What can we gain from CFD Simulation?

## Air movement and Aerosol Transport

- Insights
  - Maximise fresh-air penetration and identify recirculation dead-spots
  - Understand where contamination sources could spread
  - Understand and use the concept of air-curtains
  - Design furniture placement and occupant placement to minimize transmission risk
  - Understand where particles deposit on surfaces
- Metrics
  - Age of the air (hrs/mins/sec) everywhere in the enclosure
  - Fresh Air Index (FAI) – a measure to compare the local air freshness versus the enclosure ventilation rating (air-changes per hour)
  - Contamination source index (CAI) – arising from super-spreaders coughing/breathing/talking
    - How CAI interacts with FAI
  - Air filtration/cleaning (UV/ionization/plasma) devices for efficient placement
    - Interaction with CAI
    - Interaction with surface contamination

# What are the Underlying Flow Regimes?




## Air movement and Aerosol Transport

- Fluid Dynamics
  - CFD (Computational Fluid Dynamics) solves the ***Navier-Stokes equations governing continuum fluid mechanics*** using a finite-volume approach and high-performance computing (HPC)
  - Turbulence
  - Buoyancy
  - Heat fluxes and Radiation
  - Transient Impulses (cough, breathing ...)
- Aerosols particulates
  - CFD (Computational Fluid Dynamics) additionally solves ***discrete particle mechanics fully coupled*** with the continuum fluid mechanics
  - Droplet size distribution (sub-micron up to two-orders larger)
  - Solid (pathogen) and liquid (water, fat, mucus) content
  - Heat transfer (including ultraviolet radiation) and mass transfer
  - Turbulence collision, break-up and dispersion

# Underlying Flow Regimes: Fluid Dynamics

## Turbulence

- Reynolds Number in the enclosure determines the turbulence regime
  - Turbulent, laminar, transitional
- OpenFOAM validations
  - RANS
  - LES-based



OpenFOAM: User Guide v2006  
The open source CFD toolbox

Home OpenFOAM API Man pages

▶ Command line interface <em>user@openf...</em>  
 ▶ Physical modelling  
 ▶ Boundary conditions  
 ▶ Numerics  
 ▶ Mesh motion  
 ▶ Meshing  
 ▶ Solvers  
 ▶ Parallel  
 ▶ Post-processing  
 ▶ Examples  
 ▶ Test cases  
 ▼ Verification and Validation

**Verification and Validation**

Table of Contents

- ↳ Laminar flow
- ↳ Turbulent flow
- ↳ Heat transfer
- ↳ Combustion
- ↳ Chemistry

The following sections provide links to OpenFOAM tutorial cases where the predictions are compared to reference data sets.

**Laminar flow**

- Planar Poiseuille non-Newtonian flow
- Rotating cylinders

**Turbulent flow**

- Backward facing step
- Boundary layer: wall functions
- Bump (2D)
- Decay of homogeneous isotropic turbulence
- Turbulent flat plate
- Turbulent flow over NACA0012 airfoil (2D)
- Periodic hill
- Turbulent plane channel flow with smooth walls
- Surface mounted cube
- Turbulence transition T3A

**Heat transfer**

- Buoyant cavity

**Combustion**



# Underlying Flow Regimes: Fluid Dynamics

## Buoyancy

- Laminar heated cavity
  - Wall heat flux
  - Buoyancy driven flow recirculation

### Buoyant cavity


#### Table of Contents

- ↳ Overview
- ↳ Mesh
- ↳ Results
  - ↳ Velocity distributions
  - ↳ Temperature distributions

### Overview

- Solver: `buoyantSimpleFoam`
- Investigation into natural convection in a heat cavity
- Experimental case described by Betts and Bokhari [5]
- `$FOAM_TUTORIALS/heatTransfer/buoyantSimpleFoam/buoyantCavity`

The case is described in the following figure





A temperature difference of 19.6K is maintained between the hot and cold; the remaining patches are treated as adiabatic.

### Mesh

- 3D structured mesh created using `blockMesh`

### Results

Results are presented for a selection of y/H locations






# Underlying Flow Regimes: Fluid Dynamics

## Heat flux and Radiation

- Steckler thermally stratified enclosure

- Volume heat source
- Wall heat transfer
- Enclosure radiation exchange
- Open door inflow/outflow
- Thermally stratified flow
- Outflow at the top of the door
- Inflow through the bottom
- Measurement stack along door centerline
  - Validated temperature profile
  - Validated velocity profile







# Underlying Flow Regimes: Fluid Dynamics

## Age of Air (AoA)


- Spread of “fresh” uncontaminated air from an external source
  - Open doors or windows
  - External source through Aircon or Heater
  - Air filtration units
- Passive scalar AoA (sec) solved
  - Turbulence diffusion “off” so as to maximise the convective transport physics
    - OpenFOAM test-repository
- Turbulence model effects are marginal
  - k- $\omega$ -SST vs. RNG vs. Realisable\_k- $\epsilon$
  - **k- $\omega$ -SST** selected for steady/DES consistency



Case: scalarTransport, alphaD=1, alphaDt=0, nCorr=0



Case: scalarTransport, alphaD=0, alphaDt=1, nCorr=0



# Underlying Flow Regimes: Fluid Dynamics

## Transient impulses (reduced to mean effect?)

- Respiration impulses; verifying qualitative patterns; cycles/persons are not repeatable ...
  - Spread angle and Penetration
    - Coughing (see far right >)
    - Breathing with and w/o mask (see images left)
    - Talking (see images below right)

## Fundamental protective mechanisms of face masks against droplet infections

Christian J. Kähler (Prof. Dr.) and Rainer Hain (Dr.)

Institute of Fluid Mechanics and Aerodynamics, University of the Bundeswehr Munich, Werner-Heisenberg-Weg 39, 85577 Neubiberg, Germany

Corresponding author: christian.kaehler@unibw.de

### Characterizing exhaled airflow from breathing and talking

**Abstract** The exhaled air of infected humans is one of the prime sources of contagious viruses. The exhaled air comes from respiratory events such as the coughing, sneezing, breathing and talking. Accurate information on the thermo-fluid characteristics of the exhaled airflow can be important for prediction of infectious disease transmission. The present study developed a source model to provide the thermo-fluid conditions of the exhaled air from the breathing and talking processes. The source model is a set of equations obtained from the measurements of the flow rate, flow direction, and area of mouth/nose opening

Indoor Air 2010; 20: 31–39  
www.blackwellpublishing.com/ina  
Printed in Singapore. All rights reserved

Jitendra K. Gupta<sup>1</sup>, Chao-Hsin Lin<sup>2</sup>, Qingyan Chen<sup>1</sup>

<sup>1</sup>National Air Transportation Center of Excellence for Research in the Intermodal Transport Environment (RITE), School of Mechanical Engineering, Purdue University, West Lafayette, IN, USA, <sup>2</sup>Environmental Control Systems, Boeing Commercial Airplanes, Everett, WA, USA

© 2009 John Wiley & Sons A/S

INDOOR AIR  
doi:10.1111/j.1600-0668.2009.00623.x

Breathing

Transient

Mean transient

B/C applied to steady

Coughing

1.50 m

Transient w/mask

Talking

Time: 0.2 secs

Field magQ = 0.5

# Underlying Flow Regimes: Fluid Dynamics

## Transient impulses (reduced to mean effect?)

- Respiration impulses; verifying qualitative patterns; cycles/persons are not repeatable ...
  - Spread angle and Penetration
    - Coughing (see far right >)
    - Breathing with and w/o mask (see images left)
    - Talking (see images below right)

## Fundamental protective mechanisms of face masks against droplet infections

Christian J. Kähler (Prof. Dr.) and Rainer Hain (Dr.)

Institute of Fluid Mechanics and Aerodynamics, University of the Bundeswehr Munich, Werner-Heisenberg-Weg 39, 85577 Neubiberg, Germany

Corresponding author: christian.kaehler@unibw.de

### Characterizing exhaled airflow from breathing and talking

**Abstract** The exhaled air of infected humans is one of the prime sources of contagious viruses. The exhaled air comes from respiratory events such as the coughing, sneezing, breathing and talking. Accurate information on the thermo-fluid characteristics of the exhaled airflow can be important for prediction of infectious disease transmission. The present study developed a source model to provide the thermo-fluid conditions of the exhaled air from the breathing and talking processes. The source model is a set of equations obtained from the measurements of the flow rate, flow direction, and area of mouth/nose opening



*Indoor Air* 2010; 20: 31–39  
www.blackwellpublishing.com/ina  
Printed in Singapore. All rights reserved

**Jitendra K. Gupta<sup>1</sup>, Chao-Hsin Lin<sup>2</sup>, Qingyan Chen<sup>1</sup>**

<sup>1</sup>National Air Transportation Center of Excellence for Research in the Intermodal Transport Environment (RITE), School of Mechanical Engineering, Purdue University, West Lafayette, IN, USA, <sup>2</sup>Environmental Control Systems, Boeing Commercial Airplanes, Everett, WA, USA

© 2009 John Wiley & Sons A/S

**INDOOR AIR**  
doi:10.1111/j.1600-0668.2009.00623.x



# Underlying Flow Regimes: Fluid Dynamics

## Metrics

- “Air Changes per Hour” (ACpH) and “Age of Air” (AoA)
  - “Air changes per hour” ACpH
    - Time for one-exchange = Volume (m<sup>3</sup>) / Volume flow rate (m<sup>3</sup>/hr)
    - ACpH = 1 hr / (Time for one exchange)
  - How long has the air “actually” been in the room?
    - Driven by
      - Convection
      - Diffusion
      - Recirculation
    - AoA steady-state solution unique our implementation in OpenFOAM
- **Fresh Air Index (FAI)** = AoA \* ACpH
  - Normalised measure from steady-state
    - = 1 ... Neutral rating
    - < 1 ... Air is “fresh”
    - > 1 ... air is “stale”





# Underlying Flow Regimes: Aerosols

## Droplet size distribution

- Particle trajectories
  - ILASS validation paper (2016)
  - Sprays with wide range of particle sizes
    - Particle interaction, collision, breakup and coalescence
    - Air jet and spray penetration

ILASS Americas 28th Annual Conference on Liquid Atomization and Spray Systems, Dearborn, MI, May 2016

### ECN GDI Spray G: Coupled LES Jet Primary Breakup - Lagrangian Spray Simulation and Comparison with Data

B. Befrui<sup>\*,1</sup>, A. Aye<sup>1</sup>, A. Bossi<sup>1</sup>, L. E. Markle<sup>2</sup> and D. L. Varble<sup>2</sup>




<sup>1</sup>Delphi Customer Technology Center, Bascharage, G.-D. Luxembourg

<sup>2</sup>Delphi Technical Center Rochester, Henrietta, USA

#### Abstract

Computational fluid dynamic (CFD) simulation of in-cylinder mixture preparation is an important component of the gasoline direct injection (GDI) engine spray pattern (or targeting) optimization process. A major area of shortcoming in CFD Lagrangian stochastic simulation of GDI spray is the proper account of the jet primary breakup (with regards to the initial droplet size - velocity distribution function) due to the substantial influence of nozzle geometry on the primary atomization process. The objective of this study is to assess the predictive capability of the volume-of-fluid large-eddy-simulation (VOF-LES) method for quantitative analysis of the spray primary breakup, so to enable a fully predictive analysis of the complete GDI spray processes. The paper presents results from a VOF-LES analysis of the ECN spray G seat flow and the near-field primary atomization coupled to a Lagrangian stochastic simulation method adopting the discrete droplet model (DDM). The analysis is carried out for a vaporizing n-Heptane spray injection into the atmospheric ambient. The distinction of this case, compared with previous application of the method, is the notable interaction of spray with the counter-bore walls. Hence, the interest is whether the VOF-LES method properly captures the interaction effects on the spray plume primary atomization.

The injector internal flow and jet primary breakup simulation is performed with the Open-FOAM software suite. The simulation of the spray processes - propagation, secondary atomization, and the droplet-air exchanges - are carried out using the AVL-FIRE commercial CFD code. The accuracy of the VOF-LES primary atomization data is inferred from the predictive accuracy of the simulated far-field spray plume trajectory, cone angle, droplet-size





# Underlying Flow Regimes: Aerosols

## Aerosol penetration

- Penetration in nasal passages
- Sub-micron and micrometer particle deposition
- Joint investigation with PNNL
  - Presented at the 2017 OpenFOAM Conference

Computational fluid dynamics simulations of submicrometer and micrometer particle deposition in the nasal passages of a Sprague-Dawley rat

January 2012 - *Journal of Aerosol Science* 43(1):31-44

DOI: [10.1016/j.jaerosci.2011.08.008](https://doi.org/10.1016/j.jaerosci.2011.08.008)

Authors:



**Jeffrey Schroeter**

ORCID iD 32.42 · Applied Research Associates, I...



**Julia S Kimbell**

ORCID iD 38.97 · University of North Carolina at ...





**Bahman Asgharian**



**Earl W. Tewksbury**







**Madhuri Singal**



# Underlying Flow Regimes: Aerosols

## Aerosol, flow and heat transfer interaction

- Common in ICE and Coal fired power for which OpenFOAM has been extensively deployed
- Aerosol spray atomisation models
  - hollow/solid cone injectors, injector arrays,
  - Sauter-mean diameter/velocity/trajectory droplet distribution
- Aerosol atomisation prediction
  - VoF modelling of liquid paint injection
  - LES simulation of primary atomization of liquid paint into droplets
- Aerosol-surface interactions
  - WeberNumber-based droplet/surface interaction
    - bounce,
    - shatter
    - Stick
    - film-formation
  - Transport of resulting surface liquid film
  - Full heat and mass (species) transfer with particles and surface film



# CFD (OpenFOAM®) in the COVID-19 battle

## AGENDA


- **Statement of need**
  - How effective is the internal room ventilation regarding fresh/clean air circulation?
  - What happens to viral load from contamination sources?
- **Validation of underlying flow physics**
- **Useful measures for good ventilation**
- **Some case studies**
  - Operating theatre
  - Community centre
  - Restroom
  - Canteen / restaurant
  - Assembly plant
  - Office (executive, open-plan, connected)
  - UK C-19 Mobile Testing Unit
  - Dental and Endoscopy treatment rooms with AGPs and fallow time

# Underlying Flow Regimes: Summary


## Aerosol and Flow; all physics combined

Time: 0.00 s

ESI OpenCFD




ESI OpenCFD



# Operating Theatre Demonstrator


Layout: Theatre, staff, equipment, furniture and ventilation





# Operating Theatre Demonstrator


## Standard layout – results of CFD Fresh Air Index (FAI)



- Design details:
  - Inflow rate =  $2.4 \text{ m}^3/\text{s}$
  - Volume =  $154 \text{ m}^3$
  - Design air changes per hr = 56 (one airchange every 64sec)
- FAI indicates stale air locations in the room corners (red parts in the section-sweeps)
  - This would be a good corner location for a UV-filter / superoxide-plasma device


# Operating Theatre Demonstrator

Modifying the layout – with filter device (single or dual purpose)



# Operating Theatre Demonstrator


## Standard versus Modified layout – with filter device




# Operating Theatre Demonstrator

## Modified layout – with filter device (dual purpose)

- Tracer plume (relative concentration) emitted from UV/ion-plasma device
  - Assumed passive, same properties as air
  - No further gas-phase reactions



Plane at  $x = 3.746$  m



# COVID-19 Mobile Processing Units (MPU) Commissioning

OFFICIAL – COMMERCIAL

Department of Health & Social Care

Interim Engineering Evaluation of a Mobile Processing Unit (MPU) using Loop-Mediated Isothermal Amplification (LAMP) Technology




By  
Captain G M McKenna REME  
Lieutenant I R Campbell REME

A technical engineering evaluation report to support the engineering design of a Mobile Processing unit (Van) (MPU(V)).

British Army  
Royal Electrical and Mechanical Engineers  
Department for Health and Social Care  
23 December 2020

OFFICIAL – COMMERCIAL

Department of Health & Social Care




VT 12m x 4m x 6ft 6in  
WITH ROLLER DOOR  
VT 12m x 4m x 6ft 6in

## Rapid Testing Mobile Processing Units, Van(V) and Trailer(T)

Department of Health & Social Care



**Funding body:** Innovate UK

**Project Title:** Opensource software simulations towards understanding, monitoring and controlling COVID-19 transmission by managing air, people distancing and adapting urban environments

**Project number:** 85435

**Funding Competition:** UKRI Ideas to address COVID-19 – Innovate UK de minimis Aug 2020

Jan21-Feb21



# Mobile Processing Units Commissioning

## Using CFD to de-risk concerns


- Objectives:
  - **Occupancy health and safety** – guarantee a supply and circulation of fresh air
  - **Equipment maintenance** – ensure that equipment can be operated under the manufacturers specification
  - **Inform decision making** as to the efficient placement of ventilation/heating/aircon, **written into SOP**
- Commissioning:
  - **VAN**: 35 units designed, commissioned, fitted and operating Jan-Feb 2021
  - **TRAILER**: 30 units designed, commissioned, fitted and operating Feb-Mar 2021
- Stakeholders:
  - UK Government Department of Health and Social Care
  - Ministry of Defence deployment team
  - Chief Scientific Officer, NHS team
  - UK Public benefit
- Operation:
  - Rapid testing of COVID-19 samples at mobile sites across the UK.
  - These Mobile Processing Units (MPUs) are fitted with LAMP (Loop-mediated Isothermal Amplification) equipment, in highly controlled environments designed to maintain strict temperatures and circulate fresh air to minimise cross-contamination and risk to their operators.




# Mobile Processing Units Commissioning

**Van** — safe ventilation & equipment temperatures **Trailer** — ventilation and equipment environment

- Fresh air roof intake for **occupancy ventilation**
- Heater mixing to **maintain required equipment temperatures**




- Fresh air roof intake for **occupancy ventilation**
- Auxiliary recirculation away from key equipment to **maintain calm air processing environment**




# Ventilation and heating streamlines – velocity magnitude

**Van** – safe ventilation & equipment temperatures **Trailer** – ventilation and equipment environment

- Fresh air roof intake for **occupancy ventilation**
- Heater mixing to **maintain required equipment temperatures**



- Fresh air roof intake for **occupancy ventilation**
- Auxiliary recirculation away from key equipment to **maintain calm air processing environment**




# Fresh Air Environment

**Van** — safe ventilation & equipment temperatures    **Trailer** — ventilation and equipment environment

- Fresh air roof intake for **occupancy ventilation**
- Heater mixing to **maintain required equipment temperatures**



- Fresh air roof intake for **occupancy ventilation**
- Auxiliary recirculation away from key equipment to **maintain calm air processing environment**





# Customer Sign-off - Statement of value

RE: MPU(V) CFD - statement of need and value

CR

Carter, Ross <Ross.Carter@[REDACTED]>  
Fri 22/01/2021 09:59  
To: Fred Mendonca

👍 ↶ ↷ ➡ ...

To whom it may concern,

**Mobile Processing Unit**

An engineering team from the military were activated to support the Department of Health and Social Care (DHSC) design and build mobile processing laboratories.

These units have been designed and built in unprecedented time, learning new concepts and processes not just in COVID-19 processing but the adaptability of static laboratory testing equipment for mobile use and the interpretation of regulations and emerging technical information regarding the SAR-COVID pathogen.

This emerging technical information, left a hole in our knowledge and development, which posed a significant risk to the development of our project. As a small team we had minimal leavers of understanding the risk or more importantly articulating the possible risks.

Working with Fred and his team we have been able to break apart the possible problems posed by Air flow development within our platforms. Daily engineering decision we were making to the platform, posed a significant impacts somewhere else in the design. Working with CFD, analysing the airflow and understanding the problem has allowed us to de-risk a number of significant areas of concern and more importantly has provided the team a body of evidence to the Chief Scientific Officer, NHS and their team that these platforms are developed appropriately.

Fred and his team have been instrumental in the success of this project, their support has been 100% and I could have not asked for more.

Yours sincerely,

Major Ross Carter REME  
Engineering Officer  
Royal Electrical and Mechanical Engineering



**Major Ross Carter**  
Military Embed to DHSC  
Department of Health and Social Care  
39 Victoria Street, London, SW1H 0EU  
Mobile: [REDACTED]  
VOIP: +[REDACTED]  
Email [ross.carter@dhsc.gov.uk](mailto:ross.carter@dhsc.gov.uk)  
MoD [ross.carter@mod.gov.uk](mailto:ross.carter@mod.gov.uk)







## Community Centre:


### St. Teresa's Church, in the RC Archdiocese of Southwark

- Footfall approx. 1000 persons per week
  - Ventilation effectiveness and wellbeing
- Two scenarios were simulated
  - Without occupants and furniture
  - With occupants
- Wind blowing from Office (SE) side or Lady Chapel (NW) side




# Community Centre: Church



## Westerly and Easterly wind – ventilation effectiveness



Iso Surface of Age of Air at 10 secs




Iso Surface of Age of Air at 10 secs





# Community Centre: Church

## Westerly and Easterly wind – ventilation effectiveness

Plane at x = 50344.312 m



Plane at x = 50344.312 m






# Comparison w/o and w/occupants


## Without occupants

Iso Surface of Age of Air at 10 secs



## With occupants


Iso Surface of Age of Air at 10 secs



# Comparison w/o and w/occupants



Without occupants

Plane at x = 50344.312 m



With occupants


Plane at x = 50344.312 m






# Streamlines for occupant: 1st Row


Viral load?




• Rear View



• Side view





• Isometric View




• Top View

# Streamlines for occupant: 2nd Row


Viral load?



• Rear View



• Side view



• Isometric View





• Top View




# Streamlines for occupant: 3rd Row


Viral load?




• Rear View



• Side view




• Isometric View




• Top View

# Streamlines for occupant: 4th Row


Viral load?




• Rear View



• Side view



• Isometric View




• Top View



# Streamlines for occupant: 5th Row


Viral load?




• Rear View



• Side view



• Isometric View




• Top View




# Streamlines for occupant: from Sanctuary


Viral load?




• Rear View



• Side view



• Isometric View



• Top View

# The Team – assessing Fallow time and use of “Scrubbers”

## UK-wide NHS Clinical Engineering informing CSO/PHE/SAGE on dental AGP



**Professor Tony Fisher** MBE MD MSc PhD FAHCS FIPEM FInstP FIET CEng CSci CPhys  
*Head of Department, Dept. of Medical Physics & Clinical Engineering*  
*Royal Liverpool University Hospital*  
**Trust Lead Scientist**  
*Director Merseyside Training Consortium for Medical Physics & Clinical Engineering*  
**Head of Department, Dept. of Medical Physics & Clinical Engineering**  
*Royal Liverpool University Hospital*



**Fred Mendonça**  
*Director, Physics Modelling*  
**Innovation and Discovery**  
*MD, OpenCFD Ltd*



**Claire Greaves**  
**Chief Scientist & Clinical Director**  
**Head of Medical Physics and**  
**Clinical Engineering**  
*Nottingham University Hospitals NHS Trust*



**Professor Paul White**  
**Head of Clinical Engineering**  
*Cambridge University Hospitals*  
*NHS Foundation Trust*



**Frank Mills, FCIBSE, MASHRAE**  
**Chair, CIBSE Healthcare Group**  
**Founder member of IMechE Covid 19**  
*Task Force*  
**Member of ASHRAE Epidemic Task**  
*Force*



**Peter Bill**  
**Head of Neurophysiology**  
*Regional Chief Scientist*  
*Birmingham Women's and*  
*Children's NHS Foundation Trust*





**Professor Chris Hopkins**  
**Head of Clinical Engineering**  
*Hywel Dda University Health Board*

# Dental Treatment Room – Birmingham Children's Hospital

## Thermally neutral operating mode



- VERIFIED CFD MODEL
  - Vent air supply @ 5ACpH and extract exactly balanced
    - Treatment room volume is 44.7m<sup>3</sup>,
    - 3 occupants/equipment included
  - Assessing
    - Effects of Air Scrubber (location and rate)
    - Movement of Viral load from AGP
    - Dual direction
      - Roof angled
      - Central jet



# Dental Treatment Room – Birmingham Children's Hospital

## Room averaged Age of Air

- No-scrubber - 10 mins
- UV scrubber in situ
  - **Standard** flow rate (either position) ~ **6 mins**
  - **Purge** flow rate (either position) ~ **4 mins**



~600sec (original,  
no scrubber)

Windows **open**,  
**or**, central jet

~350sec (UV  
standard flow rate)

~250sec (UV  
purge flow rate)



# Dental Treatment Room – AgeOfAir Isosurfaces (time-advance)



**NO SCRUBBER**

Thermally neutral operating mode

**360m<sup>3</sup>/h POS-1**

Iso Surface of Age of Air at 10 secs

Iso Surface of Age of Air at 10 secs







# Dental Treatment Room - Fresh Air Index (streams from patient)

**NO SCRUBBER**

Thermally neutral operating mode

**360m<sup>3</sup>/h POS-1**




# Dental Treatment Room – Fresh Air Index

**NO SCRUBBER**

Thermally neutral operating mode

**360m<sup>3</sup>/h POS-1**





# Dental Treatment Room – Birmingham Children's Hospital

## Thermally neutral operating mode – active droplets





Figure 7. (a) Histogram of the droplet size distribution. (b) The velocity distribution of the droplets. (c) The Rosin-Rammler curve fitted for our obtained experimental droplet size data with a  $29.5 \text{ ml min}^{-1}$  flow rate.

### INTERFACE

royalsocietypublishing.org/journal/rsif

#### Research



**Cite this article:** Mirbod P, Haffner EA, Bagheri M, Higham JE. 2021 Aerosol formation due to a dental procedure: insights leading to the transmission of diseases to the environment. *J. R. Soc. Interface* **18**: 20200967.


### Aerosol formation due to a dental procedure: insights leading to the transmission of diseases to the environment

Parisa Mirbod<sup>1</sup>, Eileen A. Haffner<sup>1</sup>, Maryam Bagheri<sup>1</sup> and Jonathan E. Higham<sup>2</sup>

<sup>1</sup>Department of Mechanical and Industrial Engineering, University of Illinois at Chicago, 842 W. Taylor Street, Chicago, IL 60607, USA

<sup>2</sup>School of Environmental Sciences, University of Liverpool, Liverpool, UK

PM, 0000-0002-2627-1971; EAH, 0000-0002-8284-958X; JEH, 0000-0001-7577-0913




# Open Plan Office (Elta Fans)

## Preliminary: Neutral Operation

- Open Plan Office
  - 25 occupants in sitting position
  - Desk, cabinet, table
  - 1 CO2 sensor and 2 Air quality sensor.
- Office-side
  - 3 Ceiling AC and 2 wall Ac units
  - (Neutral, Winter and Summer scenarios)
- Aims:
  - Establish good fresh-air circulation
  - Maintain temperatures for Occupant Comfort
- Outcomes:
  - Community wellbeing
  - Engender confidence among attendance
  - Due diligence assessment by facility provider
- 3D-CAD provided by Elta Fans





Active Sub-Model : EltaFansLtdOffice07-05-Iter2.vdb





# FreshAirIndex

## Z Sweep



• CO2 Sensor


• Air Quality Sensor

• Air Quality Sensor



# Correlating CO<sub>2</sub> levels predicted vs measured




Multiple-occupancy large office



# CFD (OpenFOAM®) in the COVID-19 battle

## Summary

- Expanding CFD database of enclosures



# CFD (OpenFOAM®) in the COVID-19 battle

## Closing Statements

- Are we ready for the next wave or pandemic?
- Making CFD accessible to facilities providers (CFD non-experts)
  - CFD has been around for more than 50 years
  - It is deeply validated for several underlying physics and combinations of physics
  - We've learned about "interventions" in enclosed environments for health, wellbeing and safety
    - Measure
    - Mitigate
    - Optimise
- **ventESI** – Cloud App for non-expert CFD users
  - Available for testing now
  - Open to External partners between now and Autumn
  - Innovate-UK project Nov20-Dec21 well under way
    - Several valuable stakeholder examples
    - Still open to include more "stakeholder" studies – please let me know

[fred.mendonca@esi-group.com](mailto:fred.mendonca@esi-group.com)